



Montagehinweis  
2-2 Twinschock Slip On  
SE-20-21072-01-001

**Hinweis:**

- Bei der Montage der Auspuffanlage darauf achten, dass das Motorrad sicher steht
- Motor und Auspuffanlage vor der Montage abkühlen lassen
- Anzugsmomente für Schrauben müssen aus der modellspezifischen Reparaturanleitung entnommen werden
- Die Auspuffanlage vor Erstinbetriebnahme gründlich reinigen
- Alle Schrauben der Auspuffverbindungen nach 50 Km nachziehen

## Vorgehensweise:

1. Alle Auspuffschellen und Befestigungsschrauben der Endschalldämpfer lösen
2. Die originalen Endschalldämpfer abbauen
3. Die Slipon Rohre auf die Krümmer schieben. Die Slipon Rohre sind für die entsprechende Seite mit einem Körnerpunkt für Rechts und Ohne für Links zu erkennen  
**Hinweis:** Die Rohrverbindungen zur leichteren Montage und gegen Festbrennen mit der beiliegenden Keramikpaste bestreichen und zusammenschieben!
4. Die Endschalldämpfer auf das dickere Ende der Slip On Rohre aufschieben. Die Endschalldämpfer sind für die entsprechenden Seiten an den Auspuffflaschen mit „R“ und „L“ gekennzeichnet
5. Die Haltetaschen der Endschalldämpfer werden mit der beigelegten Inbusschraube M 8x35, einer Unterlegscheibe und Aludistanzhülse von **außen** mit der Distanzscheibe **zwischen** Auspuffflasche und Fußrastenausleger am unteren Loch des Fußrastenauslegers (Montageloch für die Fußraste) montiert. Die Endschalldämpfer können auch mit den originalen Fußrasten montiert werden
6. Die Auspuffanlage ausrichten und alle Schraubverbindungen, vom Auslass beginnend, nach hinten festziehen

Viele Grüße vom Sport-Evolution Team!



Anbau zeigt die rechte Seite, links ist entsprechend zu montieren!

Mounting instructions  
2-2 Twinschock Slip On  
SE-20-21072-01-001

**Hint:**

- When installing the exhaust system, make sure that the motorcycle is securely in place
- Cool down engine and exhaust system before mounting
- Tightening torques for screws must be taken from the modelspecific repair instructions
- Thoroughly clean the exhaust system before using it for the first time
- Retighten all screws of the exhaust connections after 50 km

## Procedure:

1. Loosen all exhaust clamps and silencers
2. Remove the original silencers
3. Push the slip-on pipes onto the manifolds. The slip-on pipes can be identified for the corresponding side with a centre punch point for right and without for left

**Note:** For easier assembly and to prevent burning, coat the pipe joints with the enclosed ceramic paste and push them together!

4. Push the silencers onto the larger end of the slip-on tubes  
The brackets of the silencers are marked with "R" and "L" for the corresponding sides
5. Fasten the brackets of the silencers with the enclosed Allen screw M8x35, a washer, the spacer sleeve from the **outside** with the spacer **between** the exhaust bracket and the footrest bracket (mounting hole for the footrest). The silencers can also be mounted with the original footrests
6. Align the exhaust system and tighten all screw connections, starting from the outlet, of the exhaust system from front to back, so everything is in line

Best regards from the Sport-Evolution Team!



Mounting shows the right side, left side must be mounted accordingly!