

Detent choke cable for BING carburetor

Installation instructions

- Remove choke spring
 - Remove upper choke lever*
 - o To do this, secure the choke lever with a 14 mm open-end wrench and loosen the nut with an 11 mm open-end wrench
 - Screw in adjusting screw from above approx. 50 %
 - Hook in the cross nipple* and refit the choke lever
 - The mounted cross nipple must move easily between the two choke levers, it must not be stiff
 - Press the button down. The choke lever must "hit the bottom".
 - If not, screw in the adjusting screw until the lever "hits the bottom". Slightly tighten the lock nut on the adjusting screw.
 - Finished
-
- o The lever does not need to be removed for carburetors with a clamping screw.

